TECHNICAL SPECIFICATIONS

| VIDEO | | | | |
|---------------------------|--|--|--|--|
| Fornat | DisplayPort1.2 | | | |
| Host Interface | (4) DisplayPort | | | |
| User Console Interface | (2) DisplayPort | | | |
| Max Resolution | Up to 4K (3840x2160 @30Hz) | | | |
| DDC | 5 volts p-p (TTL) | | | |
| Input Equalization | Automatic | | | |
| Input Cable Length | Up to 20 ft | | | |
| Output Cable Length | Up to 20 ft | | | |
| USB | | | | |
| Signal Type | USB 2.0, 1.1, and 1.0 w/ internal hub | | | |
| Input Interface | (2) USB Type B | | | |
| Output Interface | (2) USB 1.1 Type A for KVM Devices (2) USB 2.0 Type A Transparent | | | |
| AUDIO | | | | |
| Audio Input | (2) 3.5mm stereo audio (female) | | | |
| Audio Output | (1) 3.5mm stereo audio (female) | | | |
| POWER | | | | |
| Power Requirements | 12V DC, 2A power adapter with center-pin positive polarity | | | |
| ENVIRONMENT | | | | |
| Operating Temp | 32° to 104° F (0° to 40° C) | | | |
| Storage Temp | -4° to 140° F (-20° to 60° C) | | | |
| Humidity | 0-80% RH, non-condensing | | | |
| CONTROL | | | | |
| Front Panel | Push Buttons with LED indicators | | | |
| RS-232 | Via Serial @ 115200 bps | | | |
| Hot Keys | Via Keyboard | | | |
| OTHER | | | | |
| Emulation | Keyboard, Mouse and Video | | | |

WHAT'S IN THE BOX

NOTICE

| PART NO. | QTY | DESCRIPTION | |
|-----------|-----|--|--|
| SM-DPN-2D | 1 | 2-port, DH DP KVM Switch | |
| PS12VDC2A | 1 | 12-VDC, 2-A power adapter with center-pin positive polarity. | |
| | 1 | Quick Start Guide | |

The information contained in this document is subject to change without notice. iPGARD makes no warranty of any kind with regard to this material, including but not limited to, implied warranties of merchantability and fitness for a particular purpose. iPGARD

will not be liable for errors contained

herein, or for incidental or consequential damages in connection with the furnishing, performance, or use of this material. No part of this document may be photocopied,

reproduced, or translated into another language without the prior written consent

from iPGARD. Inc.

Smart AUDIO VIDEO INNOVATION

SM-DPN-2D

Advanced KVM Switch





20170518

Toll Free: (888)-994-7427

Phone: (702) 800-0005 Fax: (702)-441-5590

WWW.iPGARD.COM

DUAL-HEAD 2-PORT DISPLAYPORT KVM SWITCH WITH USB 2.0 SHARING

Quick Start Guide

A full manual can be downloaded from www.ipgard.com/SM-DPN-2D/

SYSTEM CONTROL

There are three ways to control the KVM Switch: Keyboard HotKeys, RS-232 Serial Commands, and Front Panel Buttons. The settings for the serial connection are as follows: Baud rate: **115200**; Data Bits: **8**; Parity: **None**; Stop Bits: **1**; Flow Control: **None**.

The following commands can be used:

| Command | Hotkey | RS-232 |
|-----------------|---------------------------------|---------------------------|
| Switch KVM | [CT][CT][#] <cr></cr> | //m[#] <cr></cr> |
| Audio Only | [CT][CT] a [#] <cr></cr> | //a[#] <cr></cr> |
| KM Only | [CT][CT] c [#] <cr></cr> | // c [#] <cr></cr> |
| USB Only | [CT][CT] u [#] <cr></cr> | //u[#] <cr></cr> |
| Learn EDID | [CT][CT] e <cr></cr> | // e <cr></cr> |
| Trigger Hotplug | [CT][CT]h <cr></cr> | // h <cr></cr> |
| Reset Software | [CT][CT] r | // r <cr></cr> |
| Get Port Status | N/A | //?? <cr></cr> |

Chart Key

[CT] = Ctrl <CR> = Carriage Return (Enter Key) [HK] = Current Hot Key Trigger

CUSTOM HOTKEY TRIGGERS

Users are able to customize the keys that trigger Hotkeys. The following keys are allowed: CT (Left/Right), Alt, Shift (Left/Right), Caps Lock, Scroll Lock, F1-F12

Change HK Trigger HK + HK + X + desired hotkey

View Current HK Trigger Use the RS-232 command: //??<CR>

Default HotKey Trigger CT (Left)

HARDWARE INSTALLATION

- 1. Ensure that power is turned off or disconnected from the unit and the computers.
- 2. Use DP cables to connect the DP output ports from each computer to the corresponding DP ports of the unit.
- 3. Use a USB cable (Type-A to Type-B) to connect a USB port on each computer to the respective USB ports of the unit.
- 4. Optionally connect a stereo audio cable (3.5mm to 3.5mm) to connect the audio output of the computers to the AUDIO IN ports of the unit.
- 5. Connect monitors to the DP console ports of the unit using DP cables.
- 6. Connect a USB keyboard and mouse in the two USB console ports.
- 7. Optionally connect stereo speakers to the AUDIO OUT port of the unit.
- 8. Finally, power on the KVM by connecting a 12VDC power supply to the power connector, and then turn on all the computers.

Note: You can connect up to 2 computers to the 2 port KVM.

